



Print media loading

3. Load print media into the printer.





4. Press the button to open print head.



Pull out the print media till it pass sensor; adjust the paper guide to be same width of print media, complete media loading.

Ribbon loading




1. Insert ribbon roller into the empty roll for ribbon collecting after printed. 2. Load the empty roll left side first, then right side.


3. Insert ribbon roller into new ribbon.	4. Press the button to open print head.
5. Load ribbon left side first and then right side, fix it well.	6. Pull out ribbon and stick into the empty roll. Make sure ribbon is flat and smooth when touch print head. Close the print head and carefully

close top cover.





*If you need more information about the product, please refer to the User's Manual in CD. *The printer specification, accessory, spare parts and program are subject to change without prior notice.



Black mark sensor