

Rubber Stick removal and installation

操作步骤 User Guide



By Allen , January 17,2022

Removing instructions

一. Removing needs:

1. Apex printer
2. Phillips screwdriver

二. Removing process:

1. Remove the baffle screws.



2. Lift the baffle up, and remove it.




3. Open the two bars under the rubber stick first inside and then up.

4. The two gear bars each break into a small



5. Rubber stick removal operation instructions are complete.



Installation instructions

一. Installation needs:

1. Apex printer
2. Phillips screwdriver
3. The glue stick

二. Installation process:

1. Place the white gear to the left, facing the machine, with the small bump on the lever going up.



2. Slide the stick down to ensure the gear is stuck in place.
3. Break the two gears of the stick down and determine if the stick is installed successfully.



4. Make sure the front baffle bumps card to and install from top down.



5. Install screws on both sides of the baffle and ensure no obvious gap at 1, install the glue stick is complete.

