Gainscha Network Inc.





Barcode Printer connect with DT50 via OTG Port

操作说明

User Guide

By Allen, January 17,2022

www.gainscha.com.tw

Operation requirements:

- 1. GA-2408T/GS-2406T/GA-3406T
- **2.PDA.**
- 3.OTG adapter
- 4.USB line

Operation steps:

- **1**. Turn printer power on.
- **2.**The OTG was inserted into the PDA.



3. The USB connection printer to the OTG is shown in Fig



4.Open the NokoAPP, as shown in Fig:



5. When open, find the Documents and click as shown:

10 ⁴⁶ 11	651 💊 🗩 🗗 🛛 🔹 🕅	🕱 ≵ IQI 62% 🗩 3:51
NokoPrint	t	REMOVE ADS
	Photos and in	nages
	Documents	
	Web pages	
^{香港检测和认证局} 香港检测 专业诚信 ×г音		
Not selected		

6.After going in, find it, and click on the PDF file you need to print as below:



7.Click in and select the printer connection type in the following figure:



8.Select the USB connection, as shown in Fig



9.After clicking, a page pop up and click "SELET MANUALLY" in the figure below:



10.Click "Select Driver" select driver page and select "Zebra" driver as shown in the figure below:



11.Select "Zebra ZP" again and click "Zebra ZP 450" in the following figure:



12.An ad page will pop up on how to click "OK" below:



- 13. Click on "PRINT" in the lower right corner
- 14. The following is the reference operation video

www.gainscha.com.tw